

# Instructions

**Tektronix**

**THM 550, THM 560 & THM 565  
TekMeter™**

**070-8840-01**

This document applies to firmware version 2.00  
and above.

**Please check for change information  
at the rear of this manual.**

Second Edition: September 1994

Copyright © Tektronix, Inc. 1993, 1994. All rights reserved. Licensed software products are owned by Tektronix or its suppliers and are protected by United States copyright laws and international treaty provisions.

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013, or subparagraphs (c)(1) and (2) of the Commercial Computer Software – Restricted Rights clause at FAR 52.227-19, as applicable.

Tektronix products are covered by U.S. and foreign patents, issued and pending. Information in this publication supercedes that in all previously published material. Specifications and price change privileges reserved.

Printed in the U.S.A.

Tektronix, Inc., P.O. Box 1000, Wilsonville, OR 97070-1000

TEKTRONIX and TEK are registered trademarks of Tektronix, Inc.

TekMeter is a registered trademark of Tektronix, Inc.

## WARRANTY

Tektronix warrants that this product will be free from defects in materials and workmanship for a period of one (1) year from the date of shipment. If any such product proves defective during this warranty period, Tektronix, at its option, either will repair the defective product without charge for parts and labor, or will provide a replacement in exchange for the defective product.

In order to obtain service under this warranty, Customer must notify Tektronix of the defect before the expiration of the warranty period and make suitable arrangements for the performance of service. Customer shall be responsible for packaging and shipping the defective product to the service center designated by Tektronix, with shipping charges prepaid. Tektronix shall pay for the return of the product to Customer if the shipment is to a location within the country in which the Tektronix service center is located. Customer shall be responsible for paying all shipping charges, duties, taxes, and any other charges for products returned to any other locations.

This warranty shall not apply to any defect, failure or damage caused by improper use or improper or inadequate maintenance and care. Tektronix shall not be obligated to furnish service under this warranty a) to repair damage resulting from attempts by personnel other than Tektronix representatives to install, repair or service the product; b) to repair damage resulting from improper use or connection to incompatible equipment; or c) to service a product that has been modified or integrated with other products when the effect of such modification or integration increases the time or difficulty of servicing the product.

**THIS WARRANTY IS GIVEN BY TEKTRONIX WITH RESPECT TO THIS PRODUCT IN LIEU OF ANY OTHER WARRANTIES, EXPRESSED OR IMPLIED. TEKTRONIX AND ITS VENDORS DISCLAIM ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. TEKTRONIX' RESPONSIBILITY TO REPAIR OR REPLACE DEFECTIVE PRODUCTS IS THE SOLE AND EXCLUSIVE REMEDY PROVIDED TO THE CUSTOMER FOR BREACH OF THIS WARRANTY. TEKTRONIX AND ITS VENDORS WILL NOT BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES IRRESPECTIVE OF WHETHER TEKTRONIX OR THE VENDOR HAS ADVANCE NOTICE OF THE POSSIBILITY OF SUCH DAMAGES.**

## Service Assurance

If you have not already purchased Service Assurance for your TekMeter, this valuable opportunity is still available.

### Advantages

- Conveniently arrange lifetime repair and calibration support.
- Priced well below the cost of a single repair or calibration.
- Tektronix metrology expertise worldwide will expand your internal resources.

**Repair Protection** provides post-warranty repair support whenever needed. You may purchase up to three years of Repair Protection.

**Calibration Services** provide annual calibration of your TekMeter, standards compliance and required audit documentation, recall assurance, and reminder notification of scheduled calibration. Calibration Services begin at the end of your first year of ownership, and you may purchase up to five years of support.

Purchase Repair Protection or Calibration Services, or both, to meet your needs. You can have confidence that your TekMeter investment is protected.

To order Service Assurance, please contact your Tektronix representative with the information below. Service Assurance may not be available in some locations outside the United States of America.

- |   |  |
|---|--|
| • Name  | • Repair Protection (1, 2, or 3 years)         |
| • Company   | • Calibration Service (1, 2, 3, 4, or 5 years) |
| • Address   | • Date of Purchase                             |
| • City, State, Postal Code                              | • Instrument Serial Number                     |
| • Country   | • TekMeter Model—THM 550, THM 560 or THM 565   |
| • Phone   |  |
| • VISA/MC and expiration date, or purchase order number |  |

## Table of Contents

General Safety Summary .....	1
Overview .....	4
Getting Started .....	5
Installing Batteries .....	5
Adjust Offset .....	6
DMM Operations .....	7
AC / DC Volts Measurement .....	8
Current Measurement .....	9
Max/Min Values .....	10
Ohms and Continuity .....	11
Diode Test .....	11
Hold Values .....	12
DMM Menus .....	13
DMM Menu Tree .....	14
DMM Main Menus .....	15
Probes .....	16
Filter .....	16
DMM Sto/Rec Menu .....	17
Scope Operations .....	19
Using Channel 1 .....	20
Using Channel 2 (THM 560 and THM 565) .....	20
Positioning Waveforms .....	21
Scaling (Sizing) Waveforms .....	22
Using Cursors .....	23
Triggering .....	24
Waveform ON/OFF .....	25
RUN/HOLD .....	25
Scope Menus .....	26

Scope Menu Tree .....	27
Scope Main Menus .....	28
Operation Mode .....	29
Measure Modes .....	30
Input Modes .....	31
Acquire Modes .....	33
Trigger Menus .....	35
Scope Sto/Rec Menu .....	37
Utility Menus .....	38
<b>Scope Applications .....</b>	<b>40</b>
Detecting Line Disturbances .....	40
Displaying PWM Motor Drive Waveforms (THM 565) .....	42
Three Phase Voltage (THM 560 and THM 565)	
Delta ( $\Delta$ ) Configuration .....	43
Three Phase Voltage (THM 560 and THM 565)	
Wye (Y) Configuration .....	45
Transformer Harmonic Derating Factor (THDF) .....	47
Measuring True Power (THM 560, THM 565) .....	48
<b>Appendix A: Specifications .....</b>	<b>49</b>
<b>Appendix B: Optional Accessories .....</b>	<b>57</b>
<b>Appendix C: Troubleshooting .....</b>	<b>59</b>
Instrument Problems .....	59
Reducing Noise Pickup .....	60
<b>Appendix D: Replaceable Parts .....</b>	<b>61</b>

## General Safety Summary

Review the following safety precautions to avoid injury and prevent damage to this product or any products connected to it.

*Only qualified personnel should perform service procedures.*

### Injury Precautions

#### Avoid Electric Overload

To avoid electric shock or fire hazard, do not apply a voltage to a terminal that is outside the range specified for that terminal.

#### Do Not Operate Without Covers

To avoid electric shock or fire hazard, do not operate this product with covers or panels removed.

#### Do Not Float Outside Limits

Do not apply a potential to any input, including the common input, that varies from ground by more than the maximum rating for the product.

#### Do Not Operate in Explosive Atmosphere

To avoid injury or fire hazard, do not operate this product in an explosive atmosphere.

### Product Damage Precautions

#### Use Proper Power Source

Do not operate this product from a power source that applies more than the voltage specified.

**Do Not Operate With Suspected Failures**

If you suspect there is damage to this product, have it inspected by qualified service personnel.

**Do Not Leave Exposed to Sunlight**

Do not store or leave this product where the LCD display will be exposed to direct sunlight for long periods of time.

**Safety Terms and Symbols****Terms in This Manual**

These terms may appear in this manual:



**WARNING.** *Warning statements identify conditions or practices that could result in injury or loss of life.*



**CAUTION.** *Caution statements identify conditions or practices that could result in damage to this product or other property.*

**Terms on the Product**

These terms may appear on the product:

**DANGER** indicates an injury hazard immediately accessible as you read the marking.

**WARNING** indicates an injury hazard not immediately accessible as you read the marking.

**CAUTION** indicates a hazard to property including the product.

**Symbols on the Product**

The following symbols may appear on the product:



**DANGER**  
High Voltage



Protective Ground  
(Earth) Terminal



**ATTENTION**  
Refer to  
Manual



Double  
Insulated

**Certifications and Compliances****Compliances**

Consult the product specifications for IEC Installation Category, Pollution Degree, and Safety Class.

## Overview

The THM 550, THM 560, and THM 565 TekMeters provide you with the features of a complete digital multimeter (DMM), and in addition, give you the power of a scope, all in a small portable package that is intuitive and simple to use.

The DMM provides true RMS AC and DC voltage readouts, resistance readouts, continuity testing with an audible signal, and a diode test mode. AC and DC current can be measured using an optional current probe. Additional DMM functions and readouts include a hold feature to freeze the display, min and max readouts to show how a signal has varied, and the instantaneous variation from the last held value ( $\Delta$  Hold).


The oscilloscope has the world's first Autoranging mode that automates operation completely, so that it always displays a usable signal without operator intervention. When desired, automatic operation can be overridden by using any control. In manual mode, the oscilloscope provides general oscilloscope coupling, triggering, and acquisition modes. Special preconfigured modes instantly set up the oscilloscope for motor testing, transformer THDF measurements, power line monitoring, and power measurements.

Waveforms, settings, and displays can be saved for future reference and use. Test setups can be saved to automate and recall test procedures in the field. Waveforms and screens can be saved in the field to compare them with field samples, and, with the optional Communications Adapter, transferred to a PC for customer reports or to monitor trends.

Whether your application is in field service or on the bench, the THM 500 series instruments are light, simple, portable, and versatile enough to meet your needs.

## Getting Started

### Installing Batteries



The low battery indicator appears in the upper right of the display when the battery voltage gets low. With alkaline batteries, you have about a half hour of battery life. With NiCd batteries, you have only about 30 seconds left.


(6) size AA batteries.

Maximum life alkaline or long-life NiCd batteries are recommended.

## Adjust Offset

Before performing any measurements using the Scope mode, adjust the offset setting. This is especially important if the THM 500 series instruments has been left without a power source for several hours.

**NOTE.** Pressing the ON/OFF button without batteries installed instantly uncalibrates the offset settings.



Display menu.

Use direction buttons to point to the channel offset selection. Adjust the offset for each channel.

Select.

The offset is set at the factory at room temperature. If operating the THM 500 series instruments at extreme temperatures, perform the offset adjustment to ensure proper scope measurements.


## DMM Operations

Meter Bar shows the measured value in a visual form.

Readout shows the measured value numerically.

Min/Max Readouts show the extent of variation of the signal over time.

Press SELECT to restart monitoring the signal variation.



Press MENU ON/OFF to display and operate the DMM menus.

Range selection switches. Press both for Autorange.

ON/OFF.



Display Controls set the DMM display mode according to the METER labels.

The METER/SCOPE button lets you select between DMM mode or scope mode.



HOLD button and readouts. The button temporarily freezes the display.

**Note:** To ensure maximum accuracy in DMM measurements, set the DMM filter for the line frequency used in your location, either 50 Hz or 60 Hz. See DMM Filter on page 16.

AC / DC Volts Measurement




Current Measurement





## Max/Min Values



The measurement window always displays the instantaneous value. The variation window displays the maximum and minimum values and the difference between the max and min measurements.

The MAX value displays the maximum value measured. This value only changes with a higher measurement value.

The MIN value displays the minimum value measured. This value only changes with a lower measurement value.


The MAX-MIN value is the measurement result of subtracting the MIN value from the MAX value.

**NOTE.** Exceeding the measurement capability of a manual range setting stops the MIN, MAX, and MAX – MIN measurements. Changing the range restarts these measurements.

Pressing the SELECT button resets the MAX, MIN, and MAX-MIN values.

The Hold and  $\Delta$ Hold values are explained on page 12.

## Ohms and Continuity




Connect probes across resistor or circuit.

Press if in scope mode.

Press once or twice to show desired display.

Press Select to turn continuity beeper on or off.

## Diode Test




Press if in scope mode.

Press to display diode test readout.

Check forward voltage drop < 2 V.


Check reverse voltage drop > 2V (infinity readout).

## Hold Values



Press the Hold button to freeze the display.


Hold shows reading at last hold.



Press the Hold button again to restart the display.

ΔHold shows the difference from last held value and the present measured value.

## DMM Menus



Display menus.

Use direction buttons to navigate through the menus.

Press SELECT if the message "PRESS SELECT TO CHOOSE" is displayed.

If "PRESS SELECT TO CHOOSE" appears, the SELECT button must be pushed to make the selection. If the message does not appear, THM 500 series instruments automatically changes to the chosen selection.

DMM Menu Tree

The following menu tree provides a quick look at the available DMM menus, helping you to locate specific menu choices. Each DMM menu is described in the following pages.

LIGHT		UTILITY	CONTRAST	ADJUST
PRINT			GRATICULE	NONE
RESET ALL				CROSSHAIR
PROBES	NORMAL			GRID
	1mV=1A		TIME OUTS	POWER OFF
	10mV=1A			BACKLIGHT
	100mV=1A		STATUS	VIEW
	1V=1A			PRINT
FILTER	50 Hz		ADJ OFFSET	CH1 OFFSET
	60 Hz			CH2 OFFSET
STO/REC	STO SCREEN		BAUD	1200
	REC SCREEN			9600
	PRINT SCRN		DIAGNOSTIC	INTERNAL
	STO SETUP			DISPLAY
	REC SETUP		TURN ON	CYCLE
				NO RESET
			DATE/TIME	RESET
				SET DATE
				SET TIME

DMM Main Menus

LIGHT  
PRINT  
RESET ALL  
PROBES  
FILTER  
STO/REC  
UTILITY

- LIGHT turns on the display backlight (THM 565 only).
- PRINT sends the current DMM display to a connected printer. The printer must use Epson-style commands and be connected through the optional THMCOM1 Communications Adapter. If a printer is not connected, press MENU ON/OFF to cancel.
- RESET ALL restores all settings to factory default. Display contrast and all saved settings, waveforms, and screens are preserved.
- PROBES lets you select between using voltage probes (normal) and current probes. See page 16.
- FILTER lets you choose the proper filter for your environment to increase your measurement accuracy. See page 16.
- STO/REC saves display screens and instrument settings to memory or recalls them. See page 17.
- UTILITY lets you change certain instrument characteristics. These settings are generally set only once. The Utility menus are identical when accessed through either the DMM or scope menus. See page 38 for descriptions of these menus.

Probes

LIGHT	
PRINT	
RESET ALL	
PROBES	NORMAL
FILTER	1mV=1A
STO/REC	10mV=1A
UTILITY	100mV=1A
	1V=1A

The Probes menu lets you specify whether a voltage (normal) or current probe is used. If using a current probe, specify the scale factor.

Filter

LIGHT	
PRINT	
RESET ALL	
PROBES	
FILTER	50Hz
STO/REC	60Hz
UTILITY	

The Filter menu lets you select what AC line noise to reject during DC measurements.




DMM Sto/Rec Menu


LIGHT	
PRINT	
RESET ALL	
PROBES	
FILTER	
STO/REC	STO SCREEN
UTILITY	REC SCREEN
	PRINT SCRN
	STO SETUP
	REC SETUP
	SCRN1 (✓)
	•
	SCRN8 (✓)
	CLEAR ALL
	•
	SCRN1 (✓)
	•
	SCRN8 (✓)
	CLEAR ALL
	•
	SCRN1 (✓)
	•
	SCRN8 (✓)
	SET1 ( )
	•
	SET8 ( )
	CLEAR ALL
	•
	SET1 ( )
	•
	SET8 ( )
	CLEAR ALL

The DMM Store/Recall menu allows you to store and recall entire screen displays and instrument setups. Saved screens can be sent to a printer directly. The number of memory locations available for each type of information to store is dependent on the THM 500 series instruments model. See memories on page 53. A check appears next to each location containing saved data.

## Scope Operations



## Using Channel 1



Connect COM and CH1 probes across signal source.


Press if in DMM mode.

Select CH1. (If the Select label is not displayed, press the POSITION/SCALE button.)

Press if not already on.

Press both buttons together to autorange.

## Using Channel 2 (THM 560 and THM 565)



Connect COM and CH2 probes across signal source.


Press if in DMM mode.

Select CH2. (If the Select label is not displayed, press the POSITION/SCALE button.)

Press if not already on.

Press both buttons together to autorange.


## Positioning Waveforms




Press to display position label.

Adjust vertical position of display.

Adjust horizontal position of display (horizontal position of trigger event). See the example below.



A horizontal position of 50% means the trigger event is at center screen.




A horizontal position of 20% means the trigger event is two divisions from the left edge of the screen.

**NOTE** A trigger event occurs when the waveform crosses the trigger threshold level. When this occurs, the waveform is displayed. See Triggering on page 24.

**NOTE** The Autorange mode is exited anytime a change to the scale factors, position, or triggering is made by the user.


## Scaling (Sizing) Waveforms




Press to display Scale label.

Press to change volts/division scale factor.

Press to change seconds/division scale factor.




Horizontal scale set to 5µ per division.  
Vertical scale is set to 200mV per division.



Horizontal scale set to 500ns per division.  
Vertical scale is set to 100mV per division.


**NOTE.** The Autorange mode is exited anytime a change to the scale factors, position, or triggering is made by the user.

## Using Cursors




Press to display Cursor label and cursor bars.

Press Select to toggle between cursor 1 (CUR 1) and cursor 2 (CUR 2).




Display and position the voltage cursors.

Display and position the time cursors.




Voltage cursors displayed.  $\Delta V$  measures the voltage between the cursors.




Time cursors displayed.  $\Delta T$  is the time measured between cursors.  $1/\Delta T$  is the frequency measurement.

## Triggering




Press to display Trigger label and trigger bar.

Select the channel to use as the trigger source.



Adjust the trigger level.


Select the trigger slope (rising or falling).



This example shows the trigger source set to channel 1 and the trigger event occurring when the rising edge of the signal exceeds 400 mV. The actual trigger point is the intersection of the trigger level (400 mV) and the horizontal position (50%).

**NOTE.** The Autorange mode is exited anytime a change to the scale factors, position, or triggering is made by the user.

## Waveform ON/OFF



Press to select which display the WAVEFORM ON/OFF button affects.

Press to turn waveform displays on or off.


CH1 is the channel 1 scope input.

CH2 is the channel 2 scope input.

M is the math waveform display last chosen (CH1-CH2 or CH1+CH2).

R is the last waveform stored in memory. See page 37.

## RUN/HOLD




Press to freeze (hold) the display, stopping the acquisition of the waveform.

Press to start (run) the display, starting the acquisition of the waveform.

Using Run and Hold does not affect the operation of the Autorange feature. Use the RUN/HOLD button to arm the scope while waiting for a trigger event when using single-shot trigger (see page 35).



### Scope Menus



Display menus.

Use direction buttons to navigate through the menus.

Press Select if the message "PRESS SELECT TO CHOOSE" is displayed.

If "PRESS SELECT TO CHOOSE" appears, the SELECT button must be pushed to make the selection. If the message does not appear, THM 500 series instruments automatically changes to the chosen selection.

### Scope Menu Tree


The menu tree below provides a quick look at the available scope menus, helping locate specific menu choices. Each scope menu is described in the following pages.

LIGHT			TRIGGER	MODE	AUTO
PRINT					NORMAL
RESET ALL				SLOPE	SINGLE
OPERATION	MANUAL			MOTOR	NEGATIVE
	AUTORANGE				POSITIVE
	LINE TEST		STO/REC	STO SCREEN	OFF
	MOTOR TEST			REC SCREEN	ON
MEASURE	NONE			PRINT SCRIN	
	TIMING			STO SETUP	
	VOLTS/DIV			REC SETUP	
	THDF			STO WAVE	
	POWER			REC WAVE	
INPUT	CH1 CPLG	DC			
		AC		UTILITY	CONTRAST
		GND			GRATICULE
	CH1 INVERT	OFF			ADJUST
		ON			NONE
	CH1 PROBE	NORMAL			CROSSHAIR
		1mV=1A			GRID
		10mV=1A		TIME OUTS	POWER OFF
		100mV=1A			BACKLIGHT
		1V=1A		STATUS	VIEW
	CH2 CPLG	NEGATIVE			PRINT
		POSITIVE		ADJ OFFSET	CH1 OFFSET
	CH2 INVERT	OFF			CH2 OFFSET
		ON		BAUD	1200
	MATH	OFF			9600
		CH1 - CH2		DIAGNOSTIC	INTERNAL
		CH1 + CH2			DISPLAY
ACQUIRE	SAMPLE			TURN ON	CYCLE
	SPIKE DETECT				NO RESET
	SMOOTH			DATE/TIME	RESET
	DYNAMIC DSP				SET DATE
					SET TIME

## Scope Main Menus

LIGHT  
PRINT  
RESET ALL  
OPERATION  
MEASURE  
INPUT  
ACQUIRE  
TRIGGER  
STO/REC  
UTILITY

- **LIGHT** turns on the display backlight (THM 565 only).
- **PRINT** sends the current scope display to a connected printer. The printer must use Epson-style commands and be connected through the optional THMCOM1 Communications Adapter. If a printer is not connected, press MENU ON/OFF to cancel.
- **RESET ALL** restores all settings to factory default. Display contrast and all saved settings, waveforms, and screens are preserved.
- **OPERATION** lets you choose the operation of the THM 500 series instruments. See page 29.
- **MEASURE** lets you choose preconfigured test setups. See page 30.
- **INPUT** lets you select signal coupling and signal invert. Current probe factors are set here. See page 31.
- **ACQUIRE** lets you select how signals are digitally acquired. See page 33.
- **TRIGGER** lets you select the characteristics the trigger signal must meet to cause a signal to display. See page 35.
- **STO/REC** saves display screens, waveforms, and instrument settings to memory or recalls them. See page 37.
- **UTILITY** lets you change certain instrument characteristics. These type of settings are generally set only once. See page 38.



## Operation Mode

LIGHT	
PRINT	
RESET ALL	
OPERATION	MANUAL
MEASURE	AUTORANGE
INPUT	LINE TEST
ACQUIRE	MOTOR TEST
TRIGGER	
STO/REC	
UTILITY	

Operation Mode selects between instrument operation.

- **MANUAL** lets you set parameters directly; this prevents all other parameters from automatically changing. Manual can be set without using the menu by directly setting any parameter.
- **AUTORANGE** sets all parameters for displayed channels based on the input waveform. Autorange can be set without using the menu by pressing the ▲ and ▼ buttons together.

---

**NOTE** The Autorange mode is exited anytime a change to the scale factors, position, or triggering is made by the user.

---

- **LINE TEST** captures transient events, such as voltage spikes and sags, on a power line. A dialog screen is displayed requesting line quality parameters. See page 40.
- **MOTOR TEST** automatically sets the THM 500 series instruments settings to 200V/div, Motor Trigger to On, and the acquisition mode to Spike Detect. This is ideal for measuring 480V inverter output signals of a Pulse Width Modulated (PWM) motor drive. See page 42.


### Measure Modes

LIGHT	
PRINT	
RESET ALL	
OPERATION	
MEASURE	NONE
INPUT	TIMING
ACQUIRE	VOLTS/AMPS
TRIGGER	THDF
STO/REC	POWER
UTILITY	

Measure selects from several automated measurement displays.

- **NONE** turns measurements off.
- **TIMING** measures the period, frequency, and duty cycle (% of time the voltage is high) of the selected channel.
- **VOLTS/AMPS** measures the maximum, minimum, and peak-to-peak voltage. Current is measured if using a current probe.
- **THDF** measures RMS, peak-to-peak, and the THDF of the waveform. See page 47.
- **POWER** (THM 560 and THM 565 only) measures the RMS current on channel 1 and the RMS voltage on channel 2. True power and the Power Factor (PF) are calculated and displayed. See page 48.

### Input Modes



Input mode selections let you choose various actions to apply to the input signal.

- **CH1 CPLG** (and **CH2 CPLG**) specifies how the input channel is electrically coupled to the input of the THM 500 series instruments.
  - DC coupling is direct connection.
  - AC coupling removes the DC component of a signal.
  - GND coupling shows the common (not ground) potential.
- **CH1 INVERT** (and **CH2 INVERT**) lets you display the signal “upside down.”

- CH1 PROBE lets you specify whether a voltage or current probe is used on channel 1. If using a current probe, the scale factor must be set to match the attached current probe.

NORMAL — Voltage input

1 mV = 1 A — Current input with a conversion factor of 1mV/A.

10 mV = 1 A — Current input with a conversion factor of 10mV/A.

100 mV = 1 A — Current input with a conversion factor of 100mV/A.


1 V = 1 A — Current input with a conversion factor of 1V/A.

- MATH (THM 560 and THM 565 only) determines the characteristics of the math waveform. The math waveform is displayed by selecting M in the channel selection.

OFF turns off the math waveform and is the same as using Waveform On/Off.

CH1-CH2 specifies the operation shown by the math waveform.

CH1+CH2 specifies the operation shown by the math waveform.




Acquire Modes


LIGHT	
PRINT	
RESET ALL	
OPERATION	
MEASURE	
INPUT	
ACQUIRE	SAMPLE
TRIGGER	SPIKE DETECT
STO/REC	SMOOTH
UTILITY	DYNAMIC DSP

ACQUIRE specifies how sampling is performed and how the waveform is displayed.

- SAMPLE (the default) takes one sample for each displayed waveform dot.
- SPIKE DETECT takes many samples and displays the most extreme sample; use this mode to capture glitches and spikes.




- SMOOTH takes many samples and displays a composite waveform, reducing apparent noise.




Smooth acts as a low pass filter with the following characteristics.

Time/Div	Frequency
200 nS	2.87 MHz
500 nS	1.18 MHz
1 $\mu$ S	531 kHz
2 $\mu$ S	256 kHz
5 $\mu$ S	126 kHz
10 $\mu$ S	62.5 kHz
20 $\mu$ S – 60 S	31.5 kHz

- **DYNAMIC DSP (Dynamic Display)** acquires multiple waveforms per screen update. It is ideal for capturing fast changing and infrequent events. This results in a “gray scaling” effect similar to analog oscilloscopes.




Trigger Menus



Trigger specifies the parameters needed to trigger the waveform display (cause a sweep).

- **MODE** sets the operation of the oscilloscope trigger.
  - AUTO automatically updates the waveform even if a trigger event is not detected.
  - NORMAL triggers a waveform sweep (display) when the waveform crosses the trigger level threshold. The waveform will not update again until the waveform crosses the trigger threshold again.
  - SINGLE triggers a waveform sweep (display) when the waveform crosses the trigger level threshold and then stops. Press the Run/Hold button to rearm for another trigger.
- **SLOPE** determines whether the scope triggers on the positive or negative going edge of the waveform as it crosses the trigger threshold level.


Alternately, press the TRIGGER button (twice if not in cursors display) then set with ◀ and ▶ buttons.
- **MOTOR** sets the trigger for motor signal detection and is designed to trigger on pulse width modulated waveforms. See page 36 for further details.



In Normal trigger mode with positive edge selected, the scope triggers on the rising edge of the waveform. However; pulse width modulated waveforms are a series of alternating positive and negative going pulses. With normal triggering, the scope cannot determine which positive pulse to trigger on, resulting in an unstable display.

In the illustration above, motor trigger adds hysteresis to the trigger level. Once the waveform crosses L1, the waveform triggers (stabilizes). The scope will not look for another trigger until the waveform crosses L2. Once L2 has been crossed, the next time the waveform crosses L1, the scope triggers again. (Crossing L2 re-arms the trigger.) Therefore, the scope will always trigger on the first positive-going pulse of the waveform allowing it to lock on the waveform and stabilize on it.


As you can see in the illustration below. Motor trigger can be used to stabilize noisy waveforms which would normally have trigger problems.



**NOTE. MOTOR TEST**, in the OPERATION menu, uses motor trigger. If motor trigger is turned off while using MOTOR TEST, the THM 500 series instruments return to manual operation.

### Scope Sto/Rec Menu


LIGHT  
PRINT  
RESET ALL  
OPERATION  
MEASURE  
INPUT  
ACQUIRE  
TRIGGER  
STO/REC  
UTILITY



The Store Recall menu allows you to store and recall entire screen displays, instrument setups, and waveforms. You can send saved screens directly to a printer. The number of memory locations available for each type of information to store is dependent on the THM 500 series model. See memories on page 53. A check appears next to each location containing saved data.

## Utility Menus

LIGHT  
PRINT  
RESET ALL  
OPERATION  
MEASURE  
INPUT  
ACQUIRE  
TRIGGER  
STO/REC  
UTILITY



- **CONTRAST** lets you control display darkness and contrast. The contrast setting is not affected by the Reset All function.
- **GRATICULE** changes the type of grid (none, crosshair, or grid) on the oscilloscope display. The graticule is not displayed when using the Meter mode.
- **TIME OUTS** let you set the amount of time before the battery saving functions activate: automatic power off and automatic backlight off.

- **STATUS** displays the instrument type and firmware. If a printer is not connected when PRINT is selected, press MENU ON/OFF to cancel.
- **ADJ OFFSET** removes any offset from the specified scope channel. This has no effect on the DMM input. You will be asked to disconnect the probe from the specified channel, and press the Select button to complete the automatic adjustment.
- **BAUD** sets communication speed (baud rate) of the printer/computer interface. This is for use with the optional THMCOM1 Communications Adapter.
- **DIAGNOSTIC** performs instrument self tests.

**NOTE** Activating the diagnostics resets all parameters and erases all stored waveforms, settings, and screens.

- **TURN ON** allows you to choose how the instrument powers on.
 



**NO RESET** lets all previous instrument settings remain when the instrument is powered off and then on.

**RESET** clears all previous instrument settings every time the instrument is powered off and then on (including when automatically powered off). Items stored in memory locations are not affected. If reset is selected, the THM 500 series instruments powers on in the AC volts meter mode. This mode is useful to always return the THM 500 series instrument to a known state after every power off.
- **DATE/TIME** (THM 565 only) lets you set the date and time for time stamping of stored waveforms and when using LINE TEST.

## Scope Applications

### Detecting Line Disturbances


Connect COM and CH1 across the line voltage.



Use menu to select THDF measurement.

Set CH1 PROBE to NORMAL.


Read RMS volts results on display.



Display menu.

Use direction buttons to show Line Test.

Select.




Select the parameter to change.

Specify line test parameters from the dialog screen.

Change the parameter.

Select.

- Set the RMS value to the voltage measured using the THDF measurement.
- Set the Frequency to the line frequency (from 45 Hz to 65 Hz in 5Hz steps).
- Set Quality to allow a percent of signal error (from a perfect sine wave) before failing the test. You have these settings to choose from: >3%, >12%, >21%, and >30%.
- Destination determines where a failed signal is written to. Choosing screen writes the failure to the screen and then continues the test. Choosing memory writes the failure to an empty location. Clear the memory locations to store the maximum amount of failures. Choosing Print sends the failure to a connected printer. The THMCOM1 Communications Adapter is required. Failures occurring while the THM 500 series instruments are writing failures are not captured.
- Filter lets you turn the 32 kHz filter on or off.




A quality window is created around the displayed waveform. This is an example only. The quality window is not displayed.

As long as the power line voltage falls within the quality window with the parameters you specified, the THM 500 series instruments will show "PASS" in the upper left corner. Press any button to cancel the test.

When a failure occurs, the THM 500 series instruments will show "FAIL" in the upper left corner. A notation of the number of failures and, in the THM 565, the time and date of the last failure.




Displaying PWM Motor Drive Waveforms (THM 565)



Connect voltage probe across the desired phase.


**WARNING.** To prevent injury or loss of life, do not make high voltage measurements without the use of safety gloves.



Display menu.

Select Motor Test.


Select.




One phase of the inverter output is displayed.

Turn on the cursors to measure time and voltage.

Three Phase Voltage (THM 560 and THM 565)  
Delta ( $\Delta$ ) Configuration



Connect CH1 across one phase and CH2 across second phase.




Select CH1 to show first phase.

Push to turn on.


Select CH2 to show second phase.

Push to turn on.



Channel 1 displays the P2 – P1 phase.


Channel 2 displays the P3 – P1 phase.




Select M to display the math waveform.

Push to turn on.

Press to turn waveform displays on or off.




The math waveform (CH1 – CH2) provides the P2 – P3 phase.




Notice that the waveforms are displayed 60° from one another.

$V_2$  and  $V_3$  are 120° apart. Since  $V_1$  is measured in the opposite direction (counterclockwise), it is displayed 180° out of phase from where it would be if measured in the clockwise direction.

## Three Phase Voltage (THM 560 and THM 565) Wye (Y) Configuration



Connect CH1 across one phase and CH2 across second phase.




Select CH1 to show first phase.

Push to turn on.


Select CH2 to show second phase.

Push to turn on.




Channel 1 displays the S1 phase.

Channel 2 displays the S2 phase.




Select CH2 to store the channel 2 waveform to memory.

Store the channel 2 waveform in a waveform memory location.



Disconnect CH2 from the second phase and connect across third phase.




Channel 1 displays the S1 phase.

Channel 2 displays the S3 phase.


The Reference waveform "R" displays the S2 phase. The THM 565 displays the date and time the reference waveform was saved.

**Note:** This measurement is only valid for steady state waveforms since one waveform is a reference waveform and two are real time waveforms.

## Transformer Harmonic Derating Factor (THDF)




Connect current probe to CH1.



Use menu to select THDF measurement.

Set current probe scale.

Read results on display.




Transformer Harmonic Derating Factor (THDF) is calculated as follows:

$$THDF = \frac{RMS\ Current \times \sqrt{2}}{Peak\ Current}$$


The THDF measurement should be performed on each phase of a transformer.

The THDF value is a first order look at harmonic currents. Excessive harmonic currents in a transformer can cause overheating of both the neutral wire and transformer. The lowest THDF value for the three phases should be used as the number to derate the transformer. For example, with THDF readings of 64.1% for phase 1 and 74% for phases 2 and 3, the transformer should only be used up to 64% of its power rating.

Measuring True Power (THM 560, THM 565)




Connect current probe to CH1, voltage probe to CH2, and a probe to COMM.



Use menu to select power measurement. Press the Select button.

Set current probe scale.

Read results on the display.



Channel 1 provides the Current waveform and the RMS current measurement is displayed.

Channel 2 provides the Voltage waveform and the RMS voltage measurement is displayed.

True power is measured and the measurement is displayed.

PF (power factor) is calculated as:

$$PF = \frac{\text{True Power}}{\text{RMS Current} \times \text{RMS Voltage}}$$

Appendix A: Specifications

To meet specifications, the instrument must have been operating continuously for five minutes within the operating temperature range specified. Specifications are warranted unless noted "typical."

Table 1: DMM Specifications

Table 1: DMM Specifications		550	560	565												
General																
Resolution	3¾ digit, –4,000 count full scale reading except as noted	•	•	•												
Input Impedance, DC or AC Volts	10 MΩ typical <10 pF typical <70 pF typical at 400 mV range	•	•	•												
Additional Readouts	MIN: minimum voltage or resistance. MAX: maximum voltage or resistance. MAX–MIN: difference between MAX and MIN. HOLD: value of the main reading when the HOLD button is pressed. ΔHOLD: difference between HOLD reading and active reading.	•	•	•												
DC Voltage																
Range and Resolution	<table><tr><th>Range</th><th>Resolution</th></tr><tr><td>400.0 mV</td><td>0.1 mV</td></tr><tr><td>4.000 V</td><td>1 mV</td></tr><tr><td>40.00 V</td><td>10 mV</td></tr><tr><td>400.0 V</td><td>100 mV</td></tr><tr><td>850 V</td><td>1 V</td></tr></table> Autorange available; selects from all ranges except 400.0 mV.	Range	Resolution	400.0 mV	0.1 mV	4.000 V	1 mV	40.00 V	10 mV	400.0 V	100 mV	850 V	1 V	•	•	•
Range	Resolution															
400.0 mV	0.1 mV															
4.000 V	1 mV															
40.00 V	10 mV															
400.0 V	100 mV															
850 V	1 V															
Accuracy	±(0.5% of reading + 5 counts)	•	•	•												
Normal Mode Rejection	> 60 dB typical at user-selectable 50 Hz or 60 Hz	•	•	•												
Common Mode Rejection	> 100 dB typical at user-selectable 50 Hz or 60 Hz	•	•	•												

Table 1: DMM Specifications (Cont.)

AC Voltage																			
Range and Resolution	All measurements are true RMS.  <table><tr><th>Range</th><th>Resolution</th></tr><tr><td>400.0 mV</td><td>0.1 mV</td></tr><tr><td>4.000 V</td><td>1 mV</td></tr><tr><td>40.00 V</td><td>10 mV</td></tr><tr><td>400.0 V</td><td>100 mV</td></tr><tr><td>600 V</td><td>1 V</td></tr></table> Autorange available; selects from all ranges except 400.0 mV.		Range	Resolution	400.0 mV	0.1 mV	4.000 V	1 mV	40.00 V	10 mV	400.0 V	100 mV	600 V	1 V	●	●	●		
Range	Resolution																		
400.0 mV	0.1 mV																		
4.000 V	1 mV																		
40.00 V	10 mV																		
400.0 V	100 mV																		
600 V	1 V																		
Accuracy	±(2% of reading + 5 counts) for 50 Hz or 60 Hz sine wave. Add 2% or reading + 5 counts for non-sinusoidal signal with crest factor <3.		●	●	●														
Ω/Resistance																			
Range and Resolution	<table><tr><th>Range</th><th>Resolution</th></tr><tr><td>400.0 Ω</td><td>0.1 Ω</td></tr><tr><td>4.000 KΩ</td><td>1 Ω</td></tr><tr><td>40.00 KΩ</td><td>10 Ω</td></tr><tr><td>400.0 KΩ</td><td>100 Ω</td></tr><tr><td>4.000 MΩ</td><td>1 KΩ</td></tr><tr><td>40.00 MΩ</td><td>10 KΩ</td></tr></table> Autorange available.		Range	Resolution	400.0 Ω	0.1 Ω	4.000 KΩ	1 Ω	40.00 KΩ	10 Ω	400.0 KΩ	100 Ω	4.000 MΩ	1 KΩ	40.00 MΩ	10 KΩ	●	●	●
Range	Resolution																		
400.0 Ω	0.1 Ω																		
4.000 KΩ	1 Ω																		
40.00 KΩ	10 Ω																		
400.0 KΩ	100 Ω																		
4.000 MΩ	1 KΩ																		
40.00 MΩ	10 KΩ																		
Accuracy	±(0.5% of reading + 2 counts) except 40 MΩ range which is ±(2% of reading + 5 counts) at ≤60% relative humidity. Derate 4 MΩ range to ±(1% of reading + 2 counts) from 60%–90% relative humidity.		●	●	●														
Diode Test																			
Range	0 to 2 Volts. Red input connector is positive.		●	●	●														
Continuity Check																			
Indication	Audible tone (optionally disabled) and a graphic displaying a closed switch is displayed when resistance <50 Ω typical.		●	●	●														

Table 2: Scope Specifications

		550	560	565
<b>Modes</b>				
Autorange (Default)	Autorange mode positions and sets the vertical and horizontal scales to between 30% and 60% of full screen (typical). After 500 ms, the process repeats if signal amplitude or period changes. Lower limits of Autorange are 50 mV/div and 100 ms/div.	•	•	•
Manual	Scope goes into manual mode when any control that alters the waveform display is activated.	•	•	•
Line Test	Will monitor a 45 to 65 Hz power waveform on CH1 and check for variations in amplitude and frequency. Abnormal events such as spikes, drop-outs, and substantial frequency variation will be captured and counted.  Automatic print of failures.  Automatic screen save on failures.  Time and date stamp on failure.		•	•
Motor Test	Will stabilize (trigger) on Pulse Width Modulated signals generated by Variable AC Motor Drives.			•
<b>Vertical</b>				
Channels	Channels (multiple channels are identical).	1	2	2
Probe Interface	Shrouded banana jack; accepts 4 mm caged-spring safety style banana plug. Use only probes incorporating 9 leaf-spring contacts.	•	•	•
Digitizers	8 bits, 25 MSamples/second.	1	2	2
Volts/Division Range	5 mV/div to 500 V/div in a 1–2–5 sequence.	•	•	•
Modes	Normal, Invert.	•	•	•
Coupling	DC, AC, COM (COM simulated).	•	•	•
Input Impedance, DC Coupled	≥975 kΩ, ≤10 pF	•	•	•
Analog Bandwidth	5 mV/div DC to 1 MHz 10 mV/div to 2 V/div DC to 5 MHz 5 V/div to 500 V/div DC to 1 MHz	•	•	•

Table 2: Scope Specifications (Cont.)

		550	560	565
<b>Vertical</b>				
Maximum Input Voltage	600 V <sub>RMS</sub> . See Surge Protection under Safety.	•	•	•
Accuracy (Vertical DC Delta Voltage Accuracy)	±(3.5% + 2 pixels), 19° C to 27° C; derate by 0.25% per °C outside that range. Derate additional 0.5% at 5 mV/div. Linear range is ±8 divisions from COM (com- mon).	•	•	•
Crosstalk Between Channels	≥100:1 at 5 MHz, with other channel connected to COM (common).		•	•
Mathematics	Subtract (CH1-CH2), Add (CH1+CH2).		•	•
<b>Acquisition</b>				
Modes	Sample (Normal), Spike Detect, Roll, Run/Hold, Smooth, Dynamic DSP.	•	•	•
Acquisition Rate	Up to five waveforms per second in all modes except Dynamic DSP. Dynamic DSP mode: up to 750 waveforms per second, which are then displayed at a slower rate.	•	•	•
<b>Horizontal</b>				
Time/Division Range	60 s/div to 200 ns/div in a 1-2-5 sequence.	•	•	•
Time Base Accuracy	±(0.1% + 1 pixel)	•	•	•
Record Length	256 points	•	•	•
Spike Detect	Capture spikes down to 40 ns at all sweep speeds.	•	•	•
Single Shot	Single shot on two channels simultaneously.	•	•	•
Roll	200 ms/div to 60 s/div	•	•	•
<b>Measurements</b>				
Cursors	Voltage difference between cursors (ΔV). Time difference between cursors (ΔT). Reciprocal of ΔT in Hertz (1/ΔT).	•	•	•
Voltage (and Amps when using current probe)	Maximum (MAX), Minimum (MIN), Peak-Peak (P-P).	•	•	•
Timing	Frequency (FREQ), Period (PER).	•	•	•

Table 2: Scope Specifications (Cont.)

		550	560	565
<b>Measurements</b>				
Power	Calculates true RMS current, voltage, true power, and power factor from CH1 current (using current probe) and CH2 voltage.		•	•
THDF (Transformer Harmonic Derating Factor)	Calculated as [(RMS Current × 1.41414) ÷ Peak Current], as read from a current probe on CH1.		•	•
<b>Trigger</b>				
Source	CH1 (Default) CH2	•	•	•
Modes	Auto-Level — default when in AutoRange mode Auto — default in manual operation Normal — user selectable Single-Shot — user selectable	•	•	•
Slope	Positive or Negative slope.	•	•	•
Sensitivity (Edge-type, DC Coupled)	0.5 division — 200 mV/div to 500 V/div 1 division — 10 mV/div to 100 mV/div 2 divisions — 5 mV/div	•	•	•
<b>Waveform Display</b>				
Display Update Rate	Dynamic Display Digital Signal Processing maps up to 750 waveforms/sec on screen, simulating analog-like display.	•	•	•
<b>Memories</b>				
Setups	Each setup memory stores the complete state of instrument including the state of multimeter.	4	4	8
Waveforms	Each waveform memory stores all waveform points and scale of the selected waveform.	4	4	8
Screens	Each screen memory stores the exact information that is displayed on screen; a screen snapshot.	1	1	8

Table 3: General Specifications		550	560	565
Real Time Clock	Provides date and time stamp capability for line test events and saved waveforms.			•
<b>Display System</b>				
Display Type	Super Twisted Liquid Crystal Display (LCD)	•	•	•
Size	Width 120 mm (4.72 in) nominal, Height 60 mm (2.36 in) nominal	•	•	•
Display Resolution	256 pixels horizontal × 128 pixels vertical	•	•	•
Contrast	User adjustable	•	•	•
Backlight	Electroluminescent			•
Waveform Graticule	8 divisions vertical × 10 divisions horizontal crosshair (default), grid, or none 1 vertical division = 15 pixels 1 horizontal division = 25 pixels	•	•	•
<b>Power Source</b>				
Batteries	Six size AA cells (9 V nominal)	•	•	•
Battery Life, typical	4.5 hours continuous operation with alkaline cells (backlight off). Tested using RAYOVAC® Alkaline MAXIMUM™ batteries.  Note: Battery life is extended when used intermittently.	•	•	•
Battery Saver	User time adjustable Battery Saver feature turns the instrument off after 5 minutes, backlight off after 1 minute. Times are user adjustable.	•	•	•
Memory Retention Time	Memory holdup time when batteries are removed: eight minutes minimum, three hours typical.  Note: Memory retention is much longer (weeks or months) if even discharged batteries remain installed.	•	•	•

Table 3: General Specifications (Cont.)		550	560	565
<b>Environmental</b>				
Temperature	+0° C to +50° C Operating. –20° C to +70° C Storage.	•	•	•
Humidity, Operating	+0° C to +40° C, up to 90% RH non-condensing (60% for 4 MΩ and 40 MΩ measurements), +41° C to +50° C, 60% RH non-condensing.	•	•	•
Altitude	2,200 m (7,221 ft) operating, 12,192 m (40,000 ft) storage.	•	•	•
Random Vibration	2.66 g <sub>RMS</sub> , 5 to 500 Hz, 10 min/axis, operating. 3.48 g <sub>RMS</sub> , 5 to 500 Hz, 10 min/axis, non-operating.	•	•	•
Sine Vibration, Operating	0.06 in. displacement from 5 to 15 Hz, 0.04 in. displacement from 15 to 25 Hz, 0.02 in. displacement from 25 to 55 Hz.  Duration of test is 10 minutes at the peak resonance condition (33 Hz if no resonance is found). Test is performed on each of three axis.	•	•	•
Halfsine Shock, Operating	30 g with pulse duration of 11 ms. Three shocks per axis.  Duration of test is 10 minutes at the peak resonance condition (33 Hz if no resonance is found). Test is performed on each of three axis.	•	•	•
<b>EMC</b>				
Emissions	EN 55011 radiated, class A.	•	•	•
Immunity	IEC 801-2 electrostatic discharge — up to 8 kV, IEC 801-3 radiated immunity — 3 V/meter, 27 MHz to 500 MHz.	•	•	•
<b>Mechanical</b>				
Size	Height 140 mm (5.5 in), Width 210 mm (8.3 in), Depth 43 mm (1.7 in)	•	•	•
Weight	1 kg (2.2 lb) with Alkaline Batteries installed	•	•	•
Tripod Socket	1/4 in × 20 thread, 6.3 mm (0.25 in) deep	•	•	•

Table 3: General Specifications (Cont.)

		550	560	565
<b>Safety</b>				
Certifications	Listed UL 1244 for 600V measurements; CSA-C22.2 No 231 Series-M89	•	•	•
Surge Protection	Withstands incidental line surges up to 6 kV, minimum rise time of 1.2 $\mu$ s, maximum 50 $\mu$ s duration, minimum of 2 minutes between pulses.  Maximum volt-hertz product is 50 V-MHz.	•	•	•
Fuse	This instrument has no user-replaceable fuses.	•	•	•
General	Safety Class 2	•	•	•

Appendix B: Optional Accessories

Several accessories are available for the THM 550, THM 560, and THM 565 TekMeters.

Table 4: Optional Accessories









<b>TXMDXPB Deluxe Probe Set</b>	
	The deluxe probe set provides more configurations in a wider environmental range than the standard probes that are shipped with the THM 500 series instruments. The cables are insulated with a heat-resistant silicon insulation which can be used around hot manifolds, pipes, and soldering irons. Tips provided with the deluxe probe set have several jaws that allow connection to a wide variety of test points.
<b>THM5BAT Battery Pack</b>	
	The rechargeable battery eliminates the need to repeatedly purchase alkaline batteries. The battery pack uses long-life 750 mA/hr nickel-cadmium batteries.
<b>THM5CHG Battery Charger</b>	
	The battery charger recharges the THM5BAT Battery Pack in one hour. It can be powered from wall power or from a 12 V automobile cigarette lighter.
<b>THMCOM1 Communications Adapter</b>	
	The communications adapter provides an RS-232 adapter to connect a printer to the THM 500 series instruments or the THM 500 series instruments to a computer. The communications adapter includes a stand for easy desktop operation of the THM 500 series instruments at a comfortable viewing angle. The included AC/DC power adapter also allows the THM 500 series instruments to be operated from wall power or by 12 V power from an automobile cigarette lighter. PC-link software is included.
<b>THM5AC Power Adapter</b>	
	The AC power adapter allows you to operate the THM 500 series instruments from AC wall power.



Table 4: Optional Accessories (Cont.)

<b>THM5HCA Transport Case</b>	
	The transport case provides ultimate protection for the THM 500 series instruments when shipped or transported via commercial carrier. The transport case has room for a THM 500 series instrument, probes and accessories, and a current probe.
<b>THM5SCA Soft Case/Hands-Free Pouch</b>	
	The soft case/hands-free pouch protects the THM 500 series instruments both during use and in transport. The pouch holds a THM 500 series instrument in a viewing position with a single fully-adjustable neck strap, allowing hands-free operation. When closed, it becomes a soft carrying case. The soft case/hands-free pouch provides a compartment for the probes and probe tips.
<b>A605, A621, and A622 Current Probes</b>	
	<p>Three Tektronix current probes extend the THM 500 series instruments to handle current and power measurements. These clamp-on probes do not require disconnections to insert the meter into the circuit. All three current probes include safety banana-jack adapters to connect to the THM 500 series instruments and still allow other channel's probes to connect to the common reference.</p> <p>A605: AC only, 500 A max, 48 Hz to 1 kHz, output at 1 mV/A.</p> <p>A621: AC only, 2,000 A max, 5 Hz to 50 kHz, selectable output at 1, 10, or 100 mV/A.</p> <p>A622: AC or DC, 100 A max, DC to 100 kHz, selectable output at 10 or 100 mV/A.</p>
<b>REP4100 Service Assurance — Repair Protection</b>	
	Provides one year of post-warranty repair support. Available in one-year increments up to three years.
<b>CAL4100 Service Assurance — Calibration Services</b>	
	Provides one year of calibration support. Available in one-year increments up to five years.

## Appendix C: Troubleshooting

### Instrument Problems

If you experience trouble with your THM 500 series instrument, try these corrective actions before concluding that repair is needed.

1. Make sure you are using fresh alkaline batteries or fully charged rechargeable batteries. If you are using the AC/DC power adapter included with the THMCOM1 Communications Adapter or the THM5AC Power Adapter, make sure the adapter is plugged into an appropriate live power source.
2. If the buttons do not respond to your control or the contrast is set such that the display is unreadable, remove the power source **while the THM 500 series instrument is on**. Wait 15 minutes, then restore power and try operations.
3. If the buttons do respond to your control but you still experience difficulty, use the menu to Reset All. This puts the THM 500 series instruments into a factory default state, with the exception that the stored waveforms, setups, and screens are preserved.
4. If you still experience difficulty, use the menu to perform the diagnostics: UTILITY►DIAGNOSTIC►INTERNAL and UTILITY►DIAGNOSTIC►DISPLAY. If no error conditions are reported, check your connections and reread the usage instructions.

In rare cases, your THM 500 series instrument may require servicing. There are no user serviceable parts inside the THM 500 series instruments. For service, return the instrument to the Tektronix office in your location.

## Reducing Noise Pickup

Picking up line signal noise is a typical problem when using sensitive measurement devices such as THM 500 Series instruments.

Here are some helpful hints to limit the amount of noise picked up by the THM 500 Series instrument:

- Keep the transformer line cord away from the measurement leads.
- Twist the measurement leads together, forming a “twisted pair.”
- In some situations, you may want to use a BNC-to-dual-banana adapter. This allows you to use shielded BNC cables and probes.

## Appendix D: Replaceable Parts

Obtain replacement parts for THM 500 series instruments by contacting your distributor, the place of purchase, or your nearest Tektronix office. The replaceable parts that are available are listed below. There are no user-replaceable parts inside the THM 500 series instruments.

- Standard probe set, Tektronix part number 012-1447-xx.
- Battery holder with screws, Tektronix part number 200-4101-xx.
- Corner bumper, Tektronix part number 348-1344-xx. This part number is for one bumper.
- Instructions (manual), English language, Tektronix part number 070-8840-xx.

The Instructions are also available in these languages: French, Spanish, Portuguese, German, Italian, and Japanese.

- Performance Verification (manual), English language, Tektronix part number 070-8951-xx.